Inspection Form

Authorized **stryker** Distributor

Stryker Power-LOAD System

Serial Number:	Vehicle Number:
Reason For Service	
O New / Initial Inspection	
O Routine Maintenace	
Refurbishment	
O Other	
Inspection	
Check for loose fasteners.	
Check that the battery terminal screws are tight (torqu	ue to 9 in-lb).
Clean debris from the foot and lock location on the tra	nsfer.
Clean debris from the top of the transfer assembly and	d anchor assembly.
Clean transfer roller channels to prevent debris accum	nulation.
Inspector Evaluation	
REFURBISHED - Any faulty or broken parts and compone Equipment is in functional condition and is ready for us	ents have been replaced with Stryker OEM parts. se. Follow regularly-scheduled maintenance inspections.



ate:	Signed by:
/	oigiica by.

Inspection Form

Stryker Power-PRO Series Stretcher

ROWL	-AND	

Authorized **Stryker** Distributor

Serial Number:	Vehicle Number:	

Reason For Service

- O New / Initial Inspection
- O Routine Maintenace
- Refurbishment
- O Other

Cylinder

- All fasteners are secure.
- Inspect for and verify that there are no hydraulic fluid (red) leaks.
- Extend the cylinder rod completely and wipe down with soft cloth and household cleaner.
- Inspect the fittings and tighten as necessary.

Hydraulics

- Inspect motor mount and verify that all fasteners are secure.
- Verify that there are no hydraulic fluid leaks.
- Inspect the reservoir and verify that there are no leaks.

Cables/Wires

- Verify there is no damage or pinching of wiring harness, cable, or lines.
- Verify there are no damaged connectors.
- Check grounds and connections; verify there are no hanging wires.

Manual Backup Release Handle

verify the base extends/
retracts smoothly when the manual back-up release handle is engaged.

With 100 lbs or more on the cot, verify the cot does not lower when the manual backup release handle is pulled.

Litter

- Verify all fasteners are secure.
- Verify backrest operates properly.
- Adjust pneumatic cylinder for full range motion if required.

Base

- Verify all fasteners are secure.
- Inspect the cot frame/base.

X-Frame

Verify all fasteners are secure.

Head Section

- Verify all fasteners are secure.
- Verify the head section extends and locks properly.
- Inspect the SMRT battery housing and pole mount area for cracks or damage.

Wheels

Inspect all wheels for wear, rolling and spinning properly.

Accessories

Verify the I.V. pole operates properly.

Labels

Good

Inspector Evaluation

REFURBISHED - Any faulty or broken parts and components have been replaced with Stryker OEM parts. Equipment is in functional condition and is ready for use. Follow regularly-scheduled maintenance inspections.

Acknowledgement of Maintenance, Service, and Repair

The routine maintenance, service, or repair was completed and the equipment was evaluated with recommendations noted.

ate of Service	/Repair:		
pate of Service	/ Repair:		

Signature of Service/Repair Person:_____